

Service Manual

8920 405 10601

mini digital
cassette recorder



PHILIPS

**This documentation is valid from serial number 3650 onwards e.g. fCO1 included.
Data subject to change without notice.**

Contents

I GENERAL

1. Introduction
2. Technical Specification
3. Type Numbers

II USE OF THE MINI-DCR

1. Interfacing
2. Survey of Interface Signals
3. Timing Diagram
4. Example of an interface Flow chart
5. Operating Instructions
6. Operator Maintenance

III SERVICE INFORMATION

1. Technical Description
2. Maintenance
3. Adjustments

IV SPARE PARTS

LIST OF ILLUSTRATIONS

- Fig. 1 Physical Composition of the Mini-Cassette
Fig. 2 Physical Composition of Tape
Fig. 3 Data Block Composition
Fig. 4 WDA-Signal
Fig. 5 RDA-RDC Signal
Fig. 6 RDC timing
Fig. 7 Physical Dimensions
Fig. 8 Interface Connector
Fig. 9 Interface Diagram
Fig. 10 Timing Diagram
Fig. 11 Flowchart example
Fig. 12 Block Diagram
Fig. 13 Circuit Diagram
Fig. 14 PCB Layout
Fig. 15 RAS Signal
Fig. 16 Jitter Adjustment
Fig. 17/18 Spare parts

I General

1. INTRODUCTION

This manual provides the description, timing diagram, interfacing signals as well as operating and maintenance instructions for the Philips mini-digital cassette recorder.

The Philips Mini-DCR has been specially designed for O.E.M.'s and users that need a fast and low-cost serial memory device for data storage and interchange.

The Mini-DCR is available as a read-and-write version.

The recorder uses the Philips mini-cassettes. The whole system is based on Philips' extensive know-how gained in many years experience of digital cassette recording systems and their applications.

Advantages of economy, cassette convenience and high performance have made this technique internationally accepted and Philips quality and reliability have made them a major O.E.M. supplier of this type of equipment.

The Philips Mini-DCR is an ideal unit for micro-processor based systems, terminals, mini-computers and scientific calculators to be used in program loading, memory back-up and data capture applications.

2. TECHNICAL SPECIFICATION

| | |
|--------------------------|---|
| Number of heads | : two; a read/write head and an erase head |
| Recording head | : single gap, single track, half width, read/write head |
| Number of tracks | : two; A-side and B-side |
| Recording method | : phase encoding character/bit serial |
| Tape length | : approx. 35 m. |
| Data transfer rate | : 6000 bits per second |
| Recording density | : 330-560 bpi (13-22 b/mm) |
| Irrecoverable error rate | : 1 in 10 ⁹ bits |
| Tape transport | : single motor hub driven 338 rpm ± 5% |
| Tape speed | : 10.6-18 ips (270-450 mm/sec.) |
| Read/write time | : <96 sec. for full tape length |
| Start time read/write | : <100 msec. (after change in direction <150 msec.) |
| Stop time read/write | : 30-120 msec. |
| Start distance | : 0.6-2.0 inch (15-50 mm) (after change in direction 1.2-2.6 inch (30-65 mm)) |

| | |
|---------------|---------------------------------|
| Stop distance | : 0.2-1.0 inch (5-25 mm) |
| Rewind time | : <96 sec. |
| Data capacity | : 64k octads per track |
| Medium | : Philips 3.81 mm mini cassette |

Electronics

| | |
|--|--|
| Read/write electronics, tape transport | |
| Control logic | : one printed circuit board |
| Signal interface | : the signal interface is a MOS-compatible (HEF 4000p series) interface |
| Signal levels/ output signals | : logic "1" Vs minus 0.5V logic "0" < 0.5V |
| Signal levels/input signals | : logic "1" 9V to Vs logic "0" < 3V |
| Power interface | : DC-power Vs = 12 volt ± 5% |
| Power load | : 400 mA peak (100 msec.) 120 mA nominal 30 mA stand-by |
| Thermal dissipation | : 1.4 Watt nominal |
| Electrical connections | : via Amp. connector, 14 Pins cis serie Amp. code Housing 1-163690-3 Pin 163691-1 (loose piece) 163618 (contact strips) |

Environmental conditions

| | |
|-----------------------------|--|
| Operating temperature range | : +5°C to +55°C |
| Thermal shock | : <11°C per hour |
| Relative humidity | : 10%-90% (no condensation) |
| Air pressure | : 780-1100 mbar |
| Vibration (IEC 68-2-6) | : 5-200 Hz at 1g curve |
| Heat radiation | : direct sunlight radiation on the cassette drive is not allowed |
| Physical dimensions | : see fig. 7 |
| Weight of Mini-DCR | : about 400 grams |

3. TYPE NUMBERS

| | |
|----------------|---|
| 8920 405 10601 | MDCR with front cover and write enable switch (evaluation unit inclusive 6 cassettes) |
| 8920 405 10602 | MDCR in normal shipping package containing 20 units without cassettes |
| 8920 440 10101 | Mini cassette in plastic cover. |

II Use of the Mini-DCR

1. INTERFACING

The plug connections are given in fig. 8 and 9 and the interface signals and their function are listed in the following section. The timing diagram in fig. 10 gives information about the various interface signals and commands.

- To guard against any fire hazard the following measures should be taken:
 - insert a fuse 0.5 A in the positive leads of the 12 Volt supply;
 - the supply leads and earth leads must each have a minimum cross-section of 0.38 mm².
- It is recommended that cassettes be entirely (re-)wound before they are removed from the recorder. This prevents the tape from being touched by the fingers during loading and unloading. Formation of unwanted loops is also avoided.
- If the direction of the tape movement is changed the start time will be about 50 msec. longer. The start distance than will be between 30 and 65 mm.
- Each mini-cassette can be equipped with a write-enable plug in order to allow writing on the tape. The position of the write-enable plug determines whether writing is enabled on track 1 or 2 (see fig. 1).
- Information written in the Forward direction cannot be recovered by reverse reading due to the variation in recording density and tape speed.
- In order to avoid earth interference the signal ground and the power ground lines should be interconnected at the power supply.
- Figure 2 shows the physical composition of the tape. Figure 3 shows the composition of the data blocks.
- Initial gaps, interblock gaps and end of data gaps are all erased to the same polarity. This polarity is called the reference polarity. For this purpose the \overline{WDA} -line should remain high.

A preamble at the beginning of each block is required to synchronise the read electronics. Data shall be Phase Encode (PE)

data bit value:



line transitions:



Additional line transitions (phase line transitions) shall be given at the nominal midpoints between bit line transitions if required, to establish the proper polarity for the succeeding bits.

The preamble is used to synchronise the Read Clock (RDC) Read data is TRUE at the positive pulse edge of the signal Read Clock (RDC).

2. SURVEY OF INTERFACE SIGNALS

| Control lines | Description | If "0" | If "1" |
|--|--|---|--------------------------|
| $\overline{\text{FWD}}$ Forward | Causes tape transport in forward direction. | Initiates tape transport. | Stops tape transport. |
| $\overline{\text{REV}}$ Reverse | Causes tape transport in the reverse direction. | Initiates tape transport. | Stops tape transport. |
| $\overline{\text{WCD}}$ Write Command | Enables information entering via WDA-line. Also causes erasure of the tape. | Gate is open. | Gate is closed. |
| Status lines | | | |
| $\overline{\text{BET}}$ Begin/end of tape | Indicates whether begin of tape or end of tape has been detected. | Begin or end of tape has been detected. | |
| $\overline{\text{CIP}}$ Cassette in position | Indicates that a cassette is in position and the door has been closed. | Cassette is present. | No cassette. |
| $\overline{\text{WEN}}$ Write enable | Indicates if a write enable plug is present in the cassette (file protection). | Allows writing on tape (plug is present). | Write action prohibited. |
| Data lines | | | |
| $\overline{\text{WDA}}$ Write data | Input channel of the write amplifier accepting information in digital form to be recorded on tape. | PE-encoded data "0" is a neg. going signal. Data "1" is a positive going signal. In the gap $\overline{\text{WDA}}$ is at high level. | |
| RDC Read clock | Separately generated clock to strobe read-data free of jitter. | Positive going edge should be used to clock read-data. | |
| $\overline{\text{RDA}}$ Read data | Output channel of the read amplifier, supplies digital data that has been read from the tape. | PE encoded data "0" is negative going signal. Data "1" is a positive going signal. In the gap $\overline{\text{RDA}}$ is at high level. | |

3. TIMING DIAGRAM

See fig. 10

T1: The length depends on selected block-length and the relative position on the tape.

T2-T3-T4-T5: Depend on selected block-length, the total number of blocks and the start/stop, distances/times.

T6-T7: The pulses on the $\overline{\text{FWD}}$ line are necessary for clearing the Read Electronics.

How to use tape capacity efficiently

- Required tape capacity: 32k-bytes per track (128 blocks of 256 bytes each).
T2 = 1/3 T1; T3 = 40 msec.;
T4 = 250 msec.; T5 = 0. In case of re-write one block T4 = 350 msec.
- Required tape capacity; 24k-bytes per track (96 blocks of 256 bytes each).
T2 = 198 msec.; T3 = 40 msec.;
T4 = 450 msec.; T5 = 0.

3. Required tape capacity; 40k-bytes per track (40 blocs of 1024 bytes each).
T2 = 198 msec.; T3 = 40 msec.;
T4 = 450 msec.; T5 = 0.
4. Required tape capacity; 64k-bytes per track (1 block of 64k-bytes).
T2 = Rewind time till BOT; T3 = time to write end of data gap; T4 is not applicable.

Remarks

- During a continuous write operation (no backspace or controll-read) T3 = 0 msec. in order to obtain optimum data capacity.
- Repeated updating of a data-block positioned between two other blocks, may cause over-writing of the first part of the next data block.
- The pre-amble is used to synchronise the Read-clock (see detail A of the timing diagram).
- Read data is TRUE at the positive pulse edge of the signal Read clock.
- To read two or more blocks of data continuously it is necessary to reset Read clock in the inter-block gaps. This can be achieved by a pulse on the \overline{FWD} -line of:
 $1 \mu s < T < 0.5 \text{ msec.}$
- During Read operation signal \overline{WDA} may not change level, because this causes cross-talk on RDA.
- Signal BET indicates both begin and end of tape.
- In case of rewriting blocks, T4 should be at least 100 msec. longer as indicated.
- If the write enable switch is installed only cassette filled with the write enable plug can be recorded.
- The status signals \overline{CIP} \overline{WEN} \overline{BET} can have some bounds on leading edges.

4. EXAMPLE OF AN INTERFACE FLOW CHART

In fig. 11 an example of a flow chart is given. The flow chart illustrates a program for writing and checking 128 blocks of 256 databytes each.

5. OPERATING INSTRUCTIONS

Since the Mini-DCR is intended for use by O.E.M. customers, operation of the device will depend upon individual system requirements.

Cassette loading is accomplished by sliding up the button-adjacent to the cassette cover and inserting the mini-cassette, open end first, into the cassette cover and closing the cover.

6. OPERATORS MAINTENANCE

The only maintenance required for the user is cleaning of the read/write head every working week or 100 hours.
Use cotton wool buds moistened with ethanol.

III Service Information

1. TECHNICAL DESCRIPTION

(see fig. 12 block diagram and fig. 13 circuit diagram)

Write Data

The phase encoded (PE) \overline{WDA} -signal is input at 15 IC1 and appears in-phase at 11 IC1 and anti-phase at 9 IC1.

These two signals are applied across the read/write head when the \overline{WCD} signal 9 IC6 is LOW and the WEN switch closed (8, 9 IC9-high). Enabling IC1 (4 IC1-low) also causes a low level; from 2 IC1, to be fed via R56 to the base of TS6 causing current to flow through the erase head.

Read Data

The read signal from the read/write head is amplified via 2, 1 IC2 and applied to the pulse-shaper and rectifier circuit. The negative pulses inverted and amplified via 6, 7 IC2 and recombined with the amplified positive pulses from 8 IC2. Further shaping and squaring is carried out via TS7 and IC6.

The square-wave read data signal is level-coded via 3, 1 IC7 and appears at output pin 12 (RDA).

The read clock signal is derived from the read data signal via 2, 3 IC3 and appears at output pin 11 (RDC) to indicate a valid RDA output when positive.

The RDC signal is the strobe pulse for the \overline{RDA} signal. The one shot-time of IC3 depends on the bit time of the RDA signal, to strobe this signal always at the right time. The phase bit is then ignored.

The Flip Flop 11 12 IC7 is introduced to start at the beginning of the data always with the shortest one shot time. The preamble will then synchronise the RDC circuit.

Motor Control Logic

A low signal on either the \overline{FWD} or \overline{REV} inputs will cause switch "on" of TS2, TS5 or TS3, TS4 respectively.

The amount of current flowing through these transistors (and the motor) is controlled by TS1. TS1 is driven by the servo loop formed by the motor, the tachogenerator and IC's 4, 5 and 6.

BET and Tape Stopped Detector

A sample of the positive output from 8 IC5 is fed to 3 IC5 to hold the BET line high; should the tape jam or the motor stop, the output 8 IC5 goes negative causing a low on the \overline{BET} line.

Clear Logic

When both \overline{REV} and \overline{FWD} lines are high the CLEAR signal output at 11 IC9 goes high causing the following:

- i) \overline{BET} line high via 2 IC5.
- ii) TS1 cut-off via 12 IC5.
- iii) Preset of the RDA and RDC flip-flops IC7.

2. MAINTENANCE

The only maintenance required for the Mini-DCR is cleaning of the read/write head every week or 100 working hours. Use cotton wool buds moistened with ethanol.

Note 1

The heads are adjusted in the factory and locked. Do not try to readjust them.

Note 2

The position of the motor bracket on the chassis is a factory adjustment. Do not loosen the mounting screws.

3. ADJUSTEMENTS

3.1 Electronics

- a. The motor speed has to be adjusted with R4:
 - Use the middle part of the total tape length.
 - Connect a frequency counter to testpoint 11.
 - Adjust with R4 to a frequency of 1075 \pm 10 Hz.
- b. The amplitude of the RAS-signal has to be adjusted with R29:
 - Use a reference amplitude cassette (code nr. 5322 297 34017).
 - Write a digital signal with a frequency of 3 KHz.
 - Rewind the recorded part of the tape and measure during the first forward read-cycle the voltage on the RAS-test-point with an oscilloscope.
 - Adjust R29 to the voltage as mentioned on the reference amplitude cassette.

3.2 Mechanical

The mechanical forward/reverse switching element has two stop screws that should be adjusted individually to give minimum jitter in each direction (see fig. 16):

- Use a continuous pre recorded cassette (i.e. 3 KHz. test cassette, code nr. 5322 297 34016).

- Use the special screwdriver* that can be supplied under service code number 5322 395 54082.
- If the screw has not been turned in far enough a louder gear wheel noise is audible. (An oscilloscope connected to the RAS test-point shows that the amplitude of the signal is less stable (see fig. 15b).)
- Turn the screw clockwise until the stronger gear wheel noise just disappears, and then give the screw a further half-turn. (The oscilloscope shows a stable output voltage (see fig. 15a).)
- If the screw is turned in too far, the application of the gears is insufficient, and again a louder gear wheel noise is audible. (The jitter is again visible on the oscilloscope in the envelope of the tape output.)

* If a normal screwdriver is used, there is a great risk of it slipping out of the groove into the gears which could then be damaged. In this case the motor assembly has to be replaced.

IV Spare parts

Ersatzteile

Pièces de rechange

| Item Position Rep. | Description | Ordering Code Bestell kode No. de code | Beschreibung | Désignation |
|--------------------|-------------------------------|--|-------------------------------|----------------------------------|
| 20 | Stud | 5322 466 94584 | Stehbolzen | Tige filetée |
| 40 | Contactpin (100 pcs) | 5322 268 14103 | Kontaktstift (100 Stk.) | Broche de contact (100 pcs.) |
| 110 | pcb connector (20 contacts) | 5322 265 54006 | Platinenstecker (20 Kontakte) | Connecteur imprimé (20 contacts) |
| 120 | Keying plug | 5322 401 14191 | Tastenstecker | Fiche |
| 1270 | CIP switch assy | 5322 278 94079 | CIP-Schalter-Zus. | Ensemble commutateur CIP |
| FC01 | CIP switch assy | 5322 278 94088 | CIP-Schalter-Zus. | Ensemble commutateur CIP |
| 1380 | WEN switch assy | 5322 278 94081 | WEN-Schalter-Zus. | Ensemble commutateur WEN |
| 1420 | Front (without knob) | 5322 443 34019 | Frontplatte (ohne Knöpfe) | Face avant (sans bouton) |
| 1430 | Knob | 5322 414 64109 | Knopf | Bouton |
| 1440 | Washer for Knob | 5322 466 94583 | Unterlegscheibe für Knopf | Rondelle pour bouton |
| 2040 | Head housing assy | 5322 249 14079 | Kopfgehäuse-Zus. | Ensemble de logement de têts |
| 2050 | Contact housing (20 contacts) | 5322 267 64007 | Kontaktgehäuse (20 Kontakte) | Boîtier de contact (20 contacts) |
| 2060 | Spring (lock slide) | 5322 492 34492 | Feder (Verriegelungsschieber) | Ressort (verrou) |
| 2070 | Spring (head housing) | 5322 492 34493 | Feder (Kopfgehäuse) | Ressort (logement de tête) |
| 2080 | Guide block | 5322 520 14257 | Führungsblock | Bloc-guide |
| 2090 | Pressure bracket | 5322 405 34065 | Druckbügel | Etrier de compression |
| 2100 | Brake (without Felt) | 5322 405 24107 | Bremse (ohne Filz) | Frein (sans feutre) |
| 2110 | Spring (pressbracket) | 5322 492 34595 | Feder (Druckbügel) | Ressort (étrier de compression) |
| FC01 | Spring (pressbracket) | 5322 492 34604 | Feder (Druckbügel) | Ressort (étrier de compression) |
| 2120 | Spring (brake) | 5322 492 34596 | Feder (Bremse) | Ressort (frein) |
| 2130 | Motor assy | 5322 361 24177 | Motor-Zus. | Ensemble de moteur |
| 2140 | PCB assy | 5322 214 34258 | Platinen-Zus. | Ensemble de platine imprimée |
| FC01 | PCB assy | 5322 214 34267 | Platinen-Zus. | Ensemble de platine imprimée |
| 2150 | Brake felt | 5322 466 94585 | Bremsfilz | Feutre de frein |
| 2160 | Lock slide | 5322 466 85795 | Verriegelungsschieber | Verrou |
| | Write Enable plug | 5322 462 44357 | Schreibfreigabestopfen | Fiche d'autorisation decriture |
| R1 | C 47k. | 4822 110 63152 | | |
| R2 | C 100k. | 4822 110 63161 | | |
| R3 | C 10k. | 4822 110 63134 | | |
| R4 | P 100k. | 5322 100 10116 | | |
| R5 | M 301k. | 5322 116 54743 | | |
| R6 | C 680E | 4822 110 53103 | | |
| R7 | M 46k4 | 5322 116 50557 | | |
| R8 | M 4k64 | 5322 116 50484 | | |
| R9 | M 10k. | 5322 116 54619 | | |
| R10 | M 46k4 | 5322 116 50557 | | |

| Item Position Rep. | Description | Ordering Code Bestell kode No. de code |
|--------------------------|-------------|--|
| R11 | M 4k64 | 5322 116 50484 |
| R12 | C 120k. | 4822 110 63163 |
| R13 | C 330k. | 4822 110 63174 |
| R14 | C 1M | 4822 110 63187 |
| R15 | C 820k. | 4822 110 63185 |
| R16 | C 560E | 4822 110 63101 |
| R17 | C 270E | 4822 110 63092 |
| R18 | C 100k. | 4822 110 63161 |
| R19 | C 100k. | 4822 110 63161 |
| R20 | C 100k. | 4822 110 63161 |
| R21 | C 47k. | 4822 110 63152 |
| R22 | M 4k22 | 5322 116 50729 |
| R23 | M 16k2 | 5322 116 50593 |
| R24 | C 100k. | 4822 110 63161 |
| R25 | C 100k. | 4822 110 63161 |
| R26 | C 47k. | 4822 110 63152 |
| R27 | C 47k. | 4822 110 63152 |
| R28 | C 2M2 | 5322 111 44128 |
| R29 | P 1k. | 5322 100 10115 |
| R30 | C 680E | 4822 110 53103 |
| R31 | C 1k5 | 4822 110 63112 |
| R32 | M 10k. | 5322 116 54619 |
| R33 | M 10k. | 5322 116 54619 |
| R34 | M 187k. | 5322 116 54723 |
| R35 | M 215k. | 5322 151 52154 |
| R36 | C 4k7 | 4822 110 63125 |
| R37 | C 22k. | 4822 110 63143 |
| R38 | C 2k7 | 4822 110 63118 |
| R39 | C 47k. | 4822 110 63152 |
| R40 | C 2k2 | 4822 110 63116 |
| R41 | C 2k2 | 4822 110 63116 |
| R42 | C 2k2 | 4822 110 63116 |
| R43 | C 2k2 | 4822 110 63116 |
| R44 | C 10k. | 4822 110 63134 |
| R45 | C 10k. | 4822 110 63134 |
| R46 | C 100E | 4822 110 63081 |
| R47 | C 10k. | 4822 110 63134 |
| R48 | M 287k. | 5322 116 54741 |
| R49 | C 22k. | 4822 110 63143 |
| R50 | C 1k8 | 4822 110 63114 |
| R51 | M 34k8 | 5322 116 54661 |
| R52 | M 10k. | 5322 116 54619 |
| R53 | M 42k2 | 5322 116 50474 |
| R54 | M 3k01 | 5322 116 50524 |
| R55 | C 100E | 4822 110 63081 |
| R56 | C 10k. | 4822 110 63134 |
| R57 | C 10k. | 4822 110 63134 |
| R58 | M 390E | 5322 116 54401 |
| R59 | C 100E | 4822 110 63081 |
| R60 | C 47k. | 4822 110 63152 |
| R61 | C 2k2 | 4822 110 63116 |
| R62 | M 150k. | 5322 116 54712 |
| C1 | 470p | 4822 122 31177 |
| C2 | 2N2 | 4822 121 50415 |
| C3 | 10N | 5322 122 34041 |
| C4 | 100p | 4822 122 31081 |
| C5 | 68N | 5322 121 44137 |
| C6 | 10N | 5322 122 34041 |
| C7 | 1M | 5322 124 14075 |

| Item Position Rep. | Description | Ordering Code Bestell kode No. de code |
|-----------------------------------|--------------------|---|
| C8 | 100N | 4822 121 40334 |
| C9 | 47M | 4822 124 20477 |
| C10 | 22N | 4822 122 30103 |
| C11 | 10M | 4822 124 20697 |
| C12 | 10N | 5322 122 34041 |
| C13 | 10M | 4822 124 20697 |
| C14 | 3N9 | 4822 122 30098 |
| C15 | 470p | 4822 122 31177 |
| C16 | 560p | 4822 122 30126 |
| C17 | 22N | 4822 122 30103 |
| C18 | 680p | 4822 122 31178 |
| C19 | 100N | 5322 121 40323 |
| C20 | 1n8 | 4822 122 31164 |
| L1 | Coil | 4822 158 10224 |
| L2 | Coil | 4822 158 10224 |
| D1-D2 | BAW62 | 4822 130 30613 |
| D3 | BZX79-C6V2 | 4822 130 34167 |
| D4-D10 | BAW62 | 4822 130 30613 |
| D11 | BZX79-C9V1 | 4822 130 30862 |
| D12-D16 | BAW62 | 4822 130 30613 |
| TS1 | BD204 | 5322 130 44334 |
| TS2 | BC327 | 4822 130 40854 |
| TS3 | BC337 | 4822 130 40855 |
| TS4 | BC327 | 4822 130 40854 |
| TS5 | BC337 | 4822 130 40855 |
| TS6 | BC558 | 4822 130 40941 |
| TS7 | BC547C | 4822 130 44503 |
| IC1 | HEF4502 BP | 5322 209 14548 |
| IC2 | LM324 N | 5322 209 85899 |
| IC3 | NE555 V | 5322 209 85824 |
| IC4 | NE555 V | 5322 209 85824 |
| IC5 | LM324 N | 5322 209 85899 |
| IC6 | HEF40106 BP | 5322 209 14549 |
| IC7 | HEF4013 P | 5322 209 10002 |
| IC8 | HEF4050 P | 5322 209 14068 |
| IC9 | HEF4011 P | 5322 209 14046 |






Fig. 1



ERE 6381

Fig. 2




- A — Tape leader
- B — Initial gap
- C — Track 1
- D — Track 2
- E — Data block
- F — Interblock gap
- I — End of data gap



ERE 6380

- M — Preamble = 10101010
- N — data undefined block length least significant bit is read and written first
- O — CRC character 16 bits

Fig. 3



$T = \text{ACTUAL BIT CELL TIME}$
 $t_1 = > 0,5 \mu\text{Sec.} < 5 \mu\text{Sec.}$
 $t_2 = 40 \mu\text{Sec.} = \text{DATA VALID. TIME}$
 $t_3 = \text{NOMINAL } 0,75 T$
 MINIMUM $0,55 T$
 MAXIMUM $0,95 T$

ERE 6416

Fig. 6






Fig. 7



ERE 6378


| Pin No. | Signal | Pin No. | Signal |
|---------|------------------------------|---------|------------|
| 1 | 12V | 8 | <u>WCD</u> |
| 2 | OV (Signal Ground) | 9 | <u>REV</u> |
| 3 | OV (Power) | 10 | <u>FWD</u> |
| 4 | Earth (Protective Ground) | 11 | <u>RDC</u> |
| 6 | <u>WDA</u> | 12 | <u>RDA</u> |
| 7 | <u>BET</u> | 13 | <u>CIP</u> |
| | | 14 | <u>WEN</u> |

Fig. 8



ERE 6415

Fig. 9



ERE 6385

Fig. 10






Fig. 11

WRITE + CHECK DATA BLOCKS FOR 128 BLOCKS OF 256 DATA BYTES EACH




ERE 6377

Fig. 12



ENC 6432

Fig. 13



ERE 6456

Fig. 14





Fig. 15

ERE 6457




Fig. 16




Fig. 17




Fig. 18

